Issued April 2020 • Index No. DFB-ADAPTOR/3.7

Quick Disconnect Feeder End Adaptor Kits

For Kits

4820G, 4920, 4981, 4986, 4995

INSTALLATION INSTRUCTIONS


- Quick Disconnect Feeder End may be connected directly to a Bernard adaptor by threading quick disconnect directly into adaptor. Make all necessary power, control, and gas connections.
- Quick Disconnect Feeder End Adapter Kits are supplied with two long guide tubes (p/n 478 & 479) of different I.D.'s which must be cut to the proper length (Refer to **Cutting Guide** on page 2).
- 3. Select the proper guide tube I.D. below: 0.023" 0.052" Electrode Small I.D. 0.062" 1/8" Electrode Large I.D.
- 4. Install taper end toward feed rolls. If electrodes below 0.045" are being used, it may be advisable to grind a chisel point on the tapered end to guide electrode closer to the feed rolls.
- Procedure to determine cut length for guide tube that extends beyond quick disconnect (Refer to Illustration 1 on page 2):
 - A. Mark tube at point even with end of quick disconnect body.
 - B. Remove guide tube.


- C. Cut guide tube at a point 1-1/2" toward the taper from the area marked.
- D. Reinstall in adaptor and tighten set screw.
- 6. Procedure to determine cut length for guide tube recessed within quick disconnect (Refer to **Illustration 2** on page 2).
 - A. With small rule, measure amount guide tube is within quick disconnect body.
 - B. Using formula below, cut guide tube to proper length. Shorten guide tube from end opposite taper.
 - C. 1-1/2" minus distance measured inside the quick disconnect body equals length to be shortened.
- Insert the guide tube in the adaptor. Check guide tube length as indicated in **Illustration 3** (page 2) for proper fit and tighten set screw. E-Z Feed Adaptor Kits are supplied with pre-cut guide tubes for specific machines, as listed.


 0"
1/4"
1 _{/2} "
—— ³ / ₄ "
<u> </u>
11/4
1 ¹ / ₂ "
—— 1 ³ / ₄
o"




Illustrations










Adaptor Kits


4820G

FOR USE ON: Hobart Beta-Mig 200-2000 Models 17 & 19, Miller Migman 105




4920

FOR USE ON: Quick Disconnect, feeder end with guide tubes (2). Fits all existing Bernard adaptors



4981

FOR USE ON: Lincoln LN4, LN-5, LN-6, LN-8, LN-9



<u>ITEM</u>	PART#	<u>DESCRIPTION</u>
1	4893	Body, with Gas Barb &O-Ring
2	478	Guide Tube, Small I.D.
3	479	Guide Tube, Large I.D.
4	1571	Gas Hose
5	4908	Socket
6	1566	Gas Nut
7	4912	Snap Ring
8	1694	Lead Set (Includes 4942)
9	4991	Oetiker Clamp
10	663	Hose Gland
11	1381	Adaptor Body
12	1384	Set Screw
13	4942	Wire Assembly

DESCRIPTION

Gas Hose

Snap Ring

Terminals

Set Screw

Adaptor Body

Wire Assembly

Oetiker Clamp


Socket

Body, with Gas Barb & O-Ring

Guide Tube, Small I.D.

Guide Tube, Large I.D.


FOR USE ON: Lincoln LN-7, SP-200, LN-22



ITEM	PART#	<u>DESCRIPTION</u>
1	4893	Body, with Gas Barb & O-Ring
2	478	Guide Tube, Small I.D.
3	479	Guide Tube, Large I.D.
4	1571	Gas Hose
5	4908	Socket
6	1566	Gas Nut
7	4912	Snap Ring
8	1694	Lead Assembly (includes 4942)
9	4991	Oetiker Clamp
10	663	Hose Gland
11	295	Adaptor Body
12	396	Set Screw
13	4942	Wire Assembly

4995

FOR USE ON: Miller 542 GL Swing Arc, part 079-548; Porta-MIG; Millermatic 40, 50; Migmate; Millermatic 130; Miller S-32S & S-32P



ITEM	PART#	<u>DESCRIPTION</u>
1	4893	Body, with Gas Barb & O-Ring
2	478	Guide Tube, Small I.D.
3	479	Guide Tube, Large I.D.
4	1571	Gas Hose
5	4908	Socket
6	1566	Gas Nut
7	4912	Snap Ring
8	4996	Lead Assembly (includes 4942)
9	4991	Oetiker Clamp
10	663	Hose Gland
11	1294	Adaptor Body
12	396	Set Screw
13	4942	Wire Assembly

Subject to Change – The information presented in this spec sheet is accurate to the best of our knowledge at the time of printing. Please visit BernardWelds.com for the most up-to-date information.



